

- (1.) BRASS PLATE: SIZE OF VALVE, VALVE TYPE
  NO. OF TURNS & DIRECTION TO OPEN
  VALVE MFG & YEAR INSTALL
  SYSTEM "WATER" OR "SEWER" OR "REUSE" OR "FIRE"
- (2) ANCHOR
- (3.) EIGHT (8) #4 BARS OVERLAP EACH CORNER BY 2"
- (4) 24" SQ X 4" THK. CONC. PAD SURROUNDING BOX, MIN. 3000 P.S.I. POURED IN PLACE
- (5.) SET TOP OF BOX FLUSH WITH FINISHED GRADE
- (6) HEAVY DUTY TRAFFIC BEARING CAST IRON VALVE BOX, ADJUSTABLE SCREW TYPE, 5  $\frac{1}{4}$ " DIAMETER SHAFT THAT IS LCU APPROVED
- (7) EXTENSION STEM WITH 2" OPERATING NUT AS REQUIRED, IF NUT IS MORE THAN 30" BELOW FINISH GRADE.
- (8) RISER NOT TO BEAR ON VALVE OR PIPE (RISER PIPE MATERIAL MUST BE PVC)
- (9) CAST IRON DROP COVER MARKED "WATER" OR "SEWER" OR "REUSE" OR "FIRE"
- (10.) COMPACTED SUITABLE EARTH BACKFILL
- (11) 3/4" GRANULAR MATERIAL #57 STONE
- (12) 10 GAUGE DOUBLE INSULATED COPPER LOCATING WIRE (SEE LCU DETAIL G-03)

